


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1 2 3 4 5	9761936 9758979 9759441 3191638 9759133 9762575 4449809 4449743 9758595	Literature Parts Installation Instructions Use & Care Guide Tech Sheet Conversion Instructions Safer Cooking Tips Safer Cooking Tips Cook Book Screw, 8–18 x 3/8 Screw, 8–32 X 3/8 Retainer, Gasket Pump, Drain (120v) (Includes Clamps)	13 14 15 16 17 18 19 20 21 22 23 24	4455606 9762237 4455382 4452152 4452260 9758598 4451478 9761145 4455510 9762243 9761107	Hinge Receiver Left Hand Right Hand Frame, Front Gasket, Door Bracket, Mounting Spacer, Foam Boiler Support, Insulation Reservoir (Includes Clamps) Bracket, Support Gasket, Sensor Sensor, Level Latch, Motorized	35 36 37 38 39 40 41 43 50 56	9762139 4450249 9761154 9761147 9761146 9762844 4455649 9758583	Clamp
6 7 8 9 10 11	9758832 4448520 4452158 4452163 4448972 4449748	Nut,(U-Type Clip) Top, Chassis Bumper, Door Tube, Vent Lens, Light Oven Light Assy	25 26 27 29 30 31 33 34	4455641 9758830 4455636 4449154 4449040 9758597	Side, Chassis Back, Chassis Liner, Oven (Not serviceable)	INSU	NOT ILL ILATION	Insulation, Wrap Insulation, Back Insulation, Bottom Vent

OVEN DOOR PARTS




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	4455618	B Door Liner	8	4449743	Screw, 8-32 x 3/8	15	8302092	Bracket(2nd Glass)
2		Hinge, Door	9	9759634	Retainer, Glass	16	3400832	Screw, 8-18 x 3/8
	8300577	7 R.Side	11	9759635	Spacer, Glass	19	4457103	Shield, Top Heat
	9760578	3 L.Side	12	4452316	Assy, Door Glass	20		Screw, 8-18 x 3/8
3	4449259	Glass, Inner	13	4455851	Door Handle	21		Seal, Door Top
4	4451722	2 Insulation, Door	14		Bracket, Handle	22		Heat Shield (Btm)
5	4457132	Retainer, Glass		4455803	Right Hand	24		Screw, 8-32 x .548
7	4449263	3 Glass, Inner		4455804	Left Hand	25		Bracket(3rd Glass)

INTERNAL OVEN PARTS
For Model: KDRP707RSS00
(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
2 3 4 5 6 7	4457277 4457276 3181534 4452807	Element, Broil Grill, Broiler Pan, Broiler Rack, Roasting Rack, Oven Element, Hidden Bake	9 10 11 12 13	4452226		14 15 16 17	4450039 4449154	Tray, Hidden Bake Cover, Access Screw, 8–32 x .440 Screw, 8–18 x 3/8

CONTROL PANEL PARTS




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
			l 				0704440	Olavasa
1	9758959	Panel, Control	11	9758967	Face, Control	20	9761146	Switch, Cancel
2	4452000	(Inc.Nuts,Clamps) Bracket, Display	40	4455400	Panel	41	4437210	(Drain Pump)
2 3		Bracket, Display	12 13		Bezel, Knob Knob, Control	23	9761149	Hose(Red)W/Clamps
3	3730301	Mounting	14		Knob, Temp/Time			(Inlet to Resrv'r)
4	3196537	Screw, 8–18 x 3/8	15		Knob, Selector	24	9761151	Hose(Clear)W/Clmps
5		Control, Zodiac	16		Switch, Cancel			(Inlet to Valve)
6		Screw, 6-19 x 1		4457278	Jumper	25		Switch, Oven Light
7	4455806	,	17		Switch, Enter	26		Bezel, Temp Knob
0	0750000	Control Panel	18		Button, Drain	27 28	4159450	Fitting, Drain
8	2004333	Module, Display	19	9761600	Water, Inlet	20	9/02/30	(Includes Clamp)
9 10		Nameplate			(Inc.Nuts,Clamps)	29	9762671	Clamp

TOP VENTING PARTS




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1 2 3 4 5 6	9758954 9759837 9758953 6610122	Vent, Exhaust Vent–Top Blower 60MM Vent–Bottom Transformer, Light Transformer,	7 8 9	9758956 9758999	Screw, 8–18 x 3/8 Bracket, Blower Fuse–Thermo 105c 15a/120vac Block, Terminal	14 24 25 26 27	9761155 8302143 9758985	Side, Control Top Control, Taurus (Appliance Mngr) Suppressor Control, Steam Screw, 8–32 x 3/8

COOKTOP PARTS
For Model: KDRP707RSS00
(Stainless Steel)




Illus. No.	Part No.	DESCRIPTION	Illus.	Part No.	DESCRIPTION	Illus.	Part No.	DESCRIPTION
	110.	DECORNI MOR		110.	DECCINI HON	-	110.	DECORM HOR
1		Cooktop	6	3177991	Screw, 8-18 x 1/4	10	4455031	Support,
2	4455849	Burner Head (4)	7	4457331	Grate, Burner (2)			Backsplash
3		Screw, 7-18 x 3/4	8	4457150	Grate, Filler	11	4454959	Trim, Backsplash
4	4455243	Cap, Burner (4)	9	4454961	Trim, Island	12		Screw, 8-18 x 3/8
5	4456622	Orifice Holder (4)			•	13	9782116	
		(Incl.Orifice &				15		Plate, Simmer
		Ignitor)				ı		
	3400843	Screw						

BURNER BOX AND MANIFOLD PARTS



CHASSIS PARTS
For Model: KDRP707RSS00
(Stainless Steel)



IIIus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	4452802	Vent, Bottom Lower	10	9759117 3400518		16 17	3196537	Screw, 8–18 x 3/8 Side Chassis
2	4449809	Screw, 8–18 x 3/8	''		5/16–12 x 5/8			Right Side
5		Deflector, Center	12	4455644	Gusset			Left Side
7	9761913	Vent, Center	13		Support, Channel	18	9759118	
	4453323	Gasket	14	9760672	Brace, Rear	19		Tray, Drip
		Screw (4)	15		Trim, Front	20	3400805	Screw, 8-18 x 3/8
8	3196537	Screw, 8-18 x 3/8		4452804	Right Side			
9	9759092	Bracket, Mounting Regulator			Left Side			

OPTIONAL PARTS

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
	NG WIR 242828 242820 242821 242822 242830 242823 242824 242829 242825 242831 242826 242827	Wire (12 Ga. 150 c Black) Wire (14 Ga. 150 c Black) Wire (14 Ga. 150 c Blue) Wire (14 Ga. 150 c Blue) Wire (14 Ga. 150 c Brown) Wire (14 Ga. 200 c Brown) Wire (14 Ga. 200 c Green) Wire (14 Ga. 150 c Green) Wire (14 Ga. 150 c Canage) Wire (14 Ga. 150 c Red) Wire (14 Ga. 150 c White) Wire (14 Ga. 150 c Yellow) Wire (14 Ga. 200 c Yellow)	WIR	9758957 9758957 3196896 4456549 4456626 4456626 4456626 9761098 3191506 1129449 8301668 4449809 112432 4450800	RNESS PARTS Harness, Sensor Harness, Wire (Main) Clip, Wire Harness, Wire (Spark Module) Harness, Wire (Ignitor 39") Harness, Wire (Ignitor 28") Harness, Wire (Ignitor 15") Harness, Signal Bushing, Conduit Bushing Conduit Screw Nut Screw, Ground	ADHE	591014 482338 4453192	Adhesive Loctite (1/3 oz.) Sealer, Silastic (3 oz.) Seal, Ribbon Cable Seal, Access Panel